

















The ring clutch is used in conjunction with the spread anchor system. Even under load, movement is possible and if correctly fitted uncoupling is impossible.

Note: Clutches are suitable to fit a range of anchor plate sizes as below.

0.7T to 2.5T anchor plates = 2.5T Ring Clutch

3.0T to 5.0T anchor plates = 5T Ring Clutch

5.3T to 10.0T anchor plates = 10T Ring Clutch

SWL TONNE	Code	A (mm)	B (mm)	C (mm)	Weight (Kg)
2.5	640255	265	70	27	1.80
5.0	640505	330	85	36	3.80
10.0	641005	425	110	50	9.70